

Canon: Auto Adjust Gradation

The Auto Gradation Adjustment calibrates/linearizes the machine to print its most optimum color. The adjustment is performed on the machine interface.

1. Load paper into the paper drawer.

- Paper is required to be 11x17 or larger.
- If using this adjustment as a baseline for the machine, it is recommended to print the adjustment on 28lb. Hammermill paper or similar (plain paper, 20-40lb).
- If using this adjustment to achieve optimum color for a specific job or paper, it is recommended to do the adjustment directly onto that paper.

2. Go to the Auto Adjust Gradation menu.


- Press [Settings/Registration] → [Adjustment/Maintenance] → [Adjust Image Quality] → [Auto Adjust Gradation].
- If the [Settings/Registration Shortcut] button is available on the main menu screen, select the button and choose [Auto Adjust Gradation].

3. Select Paper to Adjust.

- Select the paper loaded from step 1.

4. Perform Full Adjustment.

- Select [Full Adjust].
- Press [Start] on screen.
- Follow prompts to scan and print calibration sheets.



Optional:

If performing the Auto Gradation Adjustment frequently (ex: daily) to baseline the machine, or for non-specific paper, it may be simpler to use [Quick Adjust].

1. Follow steps 2-3 above.

2. Select [Quick Adjust].

3. Press [Start], then wait for adjustment.

- Please Note: Nothing will print out; the adjustment is done internally on the machine.

