

# NEC TELEPHONE VM USER GUIDE – **UM8700**

## Getting Started

- Press the **Voicemail** softkey
- Enter your password (default password is 0000)
- Follow the prompts to set up your mailbox

## Log in from Your Telephone

- Press **Voicemail** softkey
- Enter your password
- Follow the prompts on your phone display

## Log in from Outside the System

- Dial your direct number
- Wait for voicemail to pick up
- Press # and your extension
- Enter your password

## Log in from Another Extension

- Press the **Voicemail** softkey
- Press \*# followed by your extension
- Enter your password

## Main Menu

- 1 Listen to new messages
- 2 Record and send a message
- 3 Phone manager
- 5 Listen to saved messages
- 7 Retrieve deleted messages (Current session only)
- # Main menu options

## Message Handling Menu

- 1 Pause
- 2 Forward
- 3 Rewind 5 seconds
- 4 Delete
- 5 Save
- 6 Review
- 7 Skip
- 8 Reply
- 9 Fast-forward 5 seconds
- \* Previous menu
- # Message handling menu options

## Phone Manager Menu

- 1 Personal options
- 2 Messaging options
- \* Previous menu
- # Phone manager menu options

## Phone Manager Menu

- 1 Change message notification
- 2 Change daily reminder
- 3 Record Personal Greeting
  2. Normal greeting
  3. Record and set out-of-office greeting
- 4 Change security code
- 5 Record name
- \* Previous menu
- # Personal options menu options

## Training Links:

<http://www.loffler.com/support/training/voice-solution-training/nec-telephony-phone-systems/>

# LOFFLER