

Well Permissions Chart

Default Well Permissions

Default Well Permissions	Production				
	Administrator (Prod)	Foreman/Superintendent	Operator	Production Accountants	View Only
Basic Access/FDC Reporting	Yes	Yes	Yes	No	No
Manage Alarm Settings	Yes	Yes	Yes	No	No
Acknowledge and Clear Alarms	Yes	Yes	Yes	No	No
Manage Meter Parameters	Yes	Yes	Yes	No	No
Manage Gas Composition	Yes	No	No	No	No
Manage QTR	Yes	Yes	No	No	No

Default Schematic Permissions

Default Schematic Permissions	Operations Schematics			
	Administrator (ZMS)	Approver	Creator	Viewer
Approve Schematics	Yes	Yes	No	No
View Schematics	Yes	Yes	Yes	Yes
Edit Schematics	Yes	Yes	Yes	No
Submit Schematics for Approval	Yes	Yes	Yes	No
Subscribe to Notifications	Yes	Yes	Yes	Yes

Default Fluid Analysis Permissions

Default Fluid Analysis Permissions	Operations Fluid Analysis			
	Administrator (ZCM)	Manage Sample Points	Approver	Viewer
Manage Analysis	Yes	Yes	Yes	No
Subscribe to Notifications	Yes	Yes	Yes	Yes