



URIMAT eco/info



URIMAT eco



URIMAT compactplus



URIMAT ceramic

## Cleaning Instructions URIMAT with Siphon

URIMAT eco/info - URIMAT eco/info - URIMAT eco/info - URIMAT eco - URIMAT compactplus - URIMAT compactplus - URIMAT compactplus - URIMAT ceramic

Before maintenance please read these instructions carefully




**1**  
**Outside cleaning:**  
Spray the outside of the urinal with MB-ActiveCleaner



**2**  
Wipe it with clean household paper



**3**  
**Inside cleaning:**  
Remove the sieve and clean it



**4**  
Spray the bowl with MB-ActiveCleaner



**5**  
Clean the bowl and the visible black seal with clean household paper  
**"Don't remove the siphon"**



**6**  
Insert cleaned sieve



**7**  
Finally spray the bowl inside with MB-ActiveCleaner, but do not wipe.



**IMPORTANT!**  
During daily maintenance we suggest you spray the URIMAT with MB-ActiveCleaner, but do not wipe. URIMAT MB-ActiveCleaner has to be diluted with water (1:20).



Attention: The following cases are not covered by the guarantee:

- Improper or undesignated use;
- Repairs, which are done by non authorised service personnel;
- Changes to prefabricated parts;
- Non manufacturer certified cleaning agents;
- Non manufacturer certified spareparts or accessories;

IN ALL CASES LISTED ABOVE THE GUARANTEE WILL BE INVALID.



URIMAT ceramic



URIMAT compactplus



URIMAT eco



URIMAT eco/info

## Siphon change

URIMAT eco/info - URIMAT eco/info - URIMAT eco/info - URIMAT eco - URIMAT compactplus - URIMAT compactplus - URIMAT compactplus - URIMAT ceramic  
Before changing the Siphon please read these instructions carefully



**1.1**  
**Preparation**  
Grease the rim of the NEW siphon with Sanitary grease.



**1**  
**For ceramic bowls, only grease the bottom rim.**



**2**  
Fill the siphon with water



**3**  
Remove the sieve



**4**  
Remove the siphon



**5**  
Clean the inside of the siphon holder



**6**  
Flush through with water



**7**  
Insert the prepared siphon...



**8**  
Control the function of the siphon float by pouring about 0,5 litres of water into the bowl  
... and press the rim of the siphon down until it stans.



**9**  
Replace the cleaned or new sieve



**10**  
Finish by spraying the inside of the bowl with MB-ActiveCleaner.



**11**  
Finish



**12**  
Finish



Attention: The following cases are not covered by the guarantee:

- Improper or undesignated use;
- Repairs, which are done by non authorised service personnel;
- Changes to prefabricated parts;
- Non manufacturer certified cleaning agents;
- Non manufacturer certified spareparts or accessories;

IN ALL CASES LISTED ABOVE THE GUARANTEE WILL BE INVALID.