

2020–2023 Porsche Taycan

Basic Operation – Load & Tow Events



The power button is located left of the steering column. Press to turn on the vehicle.



The instrument cluster will illuminate, indicating the vehicle is **on**.



Shift Selector

Park Button

When the vehicle is on, it can be shifted from park to reverse/neutral/drive.

From park, raise the shifter one notch to neutral. The shift selection is indicated in the cluster at the bottom right side.

To engage **park**: press the park button next to the shift lever.

When loading the Taycan to a carrier during towing events, it can only be rolled while in the off position. The vehicle can only be steered while in the on position.

In order to steer the vehicle while loading, it will need to be turned on, steered, shifted back to neutral, then turned off to roll onto the carrier deck. Place in park during transport.

- + To turn off the vehicle, press and hold the power button.
- + To shift the vehicle, apply the brake.