

Audi Lug Bolt Covers

Decorative hub bore piloted cover



With the vehicle running, pull the nose lift switch down.



The OEM provided ring tool can be found with the vehicle's jack and tire tools.



Engage "hook" on the tool's tip through the hole in the cover and gently pull straight out, removing the cover.

