Drive 😡 Best Practices and Procedures



### 2016 Lamborghini Huracán Front Cargo Cover Release and Hood Release



Both the front cargo cover (trunk) release and the hood release are located on the driver's side kick panel.

Front cargo cover = top button



Hood = bottom button



### 2016 Lamborghini Huracán Jump Start

#### Step 1

Front cargo cover release location.





### Step 2

The vehicle's battery is behind a small trim panel in the front cargo area (trunk). The twist fasteners can be removed using a coin.



Step 3 The battery terminals are just behind the panel.





# 2016 Lamborghini Huracán Tow Eyelet



#### Location

The tow eyelet is located in either one of the two black tool kit bags in the front cargo area.





#### Procedure

The screw in provision for the tow eyelet is located behind the grille on the passenger side of the bumper. Take great care while removing this grille as it can be difficult to get out.

Remove the rubber plug from the provision.

Screw in the tow eyelet all the way to the shoulder. (Standard right hand thread)









Most Huracáns are equipped with a nose lift feature, which raises the front suspension to aid in loading the vehicle onto the carrier.

#### Step 1

Agero

The nose lift switch is located in the switch panel above the climate control:



With the vehicle running, pull the nose lift switch down.



#### Fully dropped:



Step 2

The yellow light in the instrument cluster will begin to flash. When the light stops flashing, the vehicle is fully lifted.

Fully lifted:





# 2016 Lamborghini Huracán 8-Point Carrier Tie Down



The 8-point carrier tie down is the recommended retention method for Lamborghini models.



