

ClareVision Plus Video Doorbell: Installation without a Chime


Last modified: 09/21/17

Introduction

The ClareVision Plus Video Doorbell is factory ready for use in homes without chimes. When working without a chime, connect the doorbell directly to the transformer. No additional equipment is necessary.

To connect the ClareVision Plus Video Doorbell without a chime:

1. Follow the [Clare Video Doorbell Quick-Start Guide \(DOC ID 1563\)](#), stopping at “Connecting Power To The Video Doorbell,” on page 8.
2. Connect the two doorbell leads directly to the transformer and verify that the doorbell is receiving power.



3. Continue the steps in the quick-start guide, skipping “Installation When Using a Digital Doorbell Chime,” for final setup and configuration.

Contact information

Clare Controls, LLC.
7519 Pennsylvania Ave, Suite 104
Sarasota, FL 34243

General: 941.328.3991

Fax: 941.870.9646

www.clarecontrols.com

Integrator/Dealer Support: 941.404.1072

claresupport@clarecontrols.com

Homeowner Support (ClareCare): 941.315.2273 (CARE)

help@clarecontrols.com