




The CS-KFB-10 is a portable device used to remotely control a security system. The buttons can be configured to arm, disarm, trigger panic alarms, or control home automation functions.

Features

- 5 buttons
- Supports button combinations
- Low battery indication
- Secure encrypted wireless transmissions

Enroll the Five Button Fob by placing the panel into wireless enrollment mode and pressing the away and stay arming buttons simultaneously. Alternatively, the fob can be enrolled by scanning its bar code using the Install Assist App or by entering its 8-character serial number on the interactive service provider's web portal.



Button Tips


- By default, pressing STAY and AWAY will cause a panic alarm.
- Panic alarms triggered from a fob can not be canceled from the same fob.
- The buttons can be configured in the panel settings to do different things.
- Buttons and button combinations can be used to trigger home automation scenes.

Pro Tips

In CE applications, the fob must be used near the point of exit so that arming can be verified.

To replace the battery, remove the screw on the back of the fob and unsnap the back from the cover. Replace the battery and reinstall the cover.









Specifications

Physical	
Housing Dimensions Weight with Battery	2.2 x 1.5 x .6 inches (5.6 x 3.8 x 1.4 centimeters) 0.66 ounces (19 grams)
Environmental	one canon (17 grama)
Operating Temperature Maximum Humidity	32°F to 120°F (0°C to 49°C) 85% non-condensing relative humidity
Sensor Specifications	
Frequency Replacement Battery Nominal Battery Life Transmitted Indications	433.92 MHz One Panasonic CR2032 5 Years Low Battery
Certification	
RE600-5	FCC, IC, RCM, EN 60950-1, EN 300 220, EN 301 489, CE Security Grade 1, CE Environmental Class 2

Specifications subject to change without notice



Original document below https://bit.ly/2tAqCwK