



POWER & CHARGING

Turn On	Press and hold power button
Turning Bridge Off	Press & hold button until beeping stops
Wake Up Display	Press the power button
Green Power Light	Flashing - connecting Solid - powered & monitored Light off - powered off or battery is depleted
Charging Bridge	Plug into wall or car charger, connect cable, attach to Loner Bridge, leave on charger when not in use.
Red Charging Light	Flashing - charging Solid - charged Light off - not charging
Low Battery	Loner Bridge chirps & flashes every 5 minutes

OPERATIONS

Placement	Eye level, ensuring Loner Bridge has clear view of the sky - higher placement allows further range to Loner 900
Operating Temperature	-40° to 55°C
Cellular vs Satellite	Loner Bridge switches to satellite if GSM is unavailable
Run Time	44 hour run time on full charge
Range to Loner	2km range typical (dependent on terrain)

CONTACT US

North America & International
 Customer Support:
 +1-877-869-7212 | support@blacklinesafety.com

Europe
 Customer Support:
 +44 1787 222684 | eusupport@blacklinesafety.com