

DYNAWASH ⁸²⁵ QUICK START

Before each use, inspect the lint filter and clean if necessary.

Heater On / Off	This is the Dynawash control panel. The buttons and indicators are self-explanatory. Ensure the bath is filled with water to the fill marker (approx. 40 litres). Switch on the power and the display quickly goes through a self-test.
Temperature A S P A A S C P C	To set the temperature: Press the P button on the Temperature controller. SP 1 (set-point) is displayed. Use the ↑↓ buttons to increase or decrease the temperature set-point.
Temperature A C C C C C C C C C C C C C C C C C C C	Press the P button again to Program the required temperature set-point. A = A ctual temperature of water S = temperature S et-point
Timer Mute Start Stop () P ()	To set the timer: Press the P button on the Timer controller. <i>t 1</i> is displayed.
Timer Mute Start Stop P	Use the ↑ ↓ buttons to increase or decrease the time. Press the Start Stop button to set the new Timer set-point.

Heater On / Off Star	Press the <i>Heater</i> button to switch the electric heater on. Press the <i>Start</i> button to start the impeller turning in the water bath. Note: the impeller will not start if the lid is open. Note: always run the impeller while heating.
A E C C C C C C C C C C C C C C C C C C	Prepare specimen, detergent and makeweights as required. When set temperature is achieved, add detergent and run for approx. 1 minute. If required, add makeweights and run for approx. 1 minute.
Timer Mute Start Stop P	Add specimen, close lid and Start impeller. Start the Timer by pressing the Start Stop button on the Timer. The Timer will count down displaying <i>mm:ss</i> . The Timer will count down to zero.
Timer End	buzzer will sound to alert the operator.
	Open the lid and remove the specimen first, then remove the makeweights. Rinse and dry the specimen and makeweights, as required.
Pump On / Off	To empty the bath, ensure the heater is off. Press the <u>Pump</u> button to drain the bath. This will take approx. 90s. When the bath is empty, rinse with clean water while the pump is running. When the bath is empty switch the <u>Pump</u> off. Wipe the exterior of Dynawash with a soft dry cloth.