

Kajeet SmartSpot® 8800

Quick Start Guide



POWER BUTTON: Powers the Kajeet SmartSpot on and wakes the device from sleep mode.

COLOR TOUCHSCREEN: Provides connection and battery status, network signal strength, and the number of connected users. Used to navigate through device menus and retrieve Wi-Fi information.

SMARTSPOT & AUXILIARY CHARGING PORT: The AC charger supplied with your SmartSpot connects here. This port can also be used to charge external devices.

The Kajeet SmartSpot® is a portable Wi-Fi hotspot that extends the school day by providing the fastest, filtered broadband access outside the classroom.



Accessing

Kajeet SmartSpot Wi-Fi Name & Password

1. Make sure your Kajeet SmartSpot is powered on and is on the home screen (if the screen is off, press the power button to exit sleep mode).
2. On the screen, press the 'Wi-Fi Name and Password' button. The screen will display the Wi-Fi name and password of the SmartSpot.
3. When done, press the back arrow on the top left of the screen to return to the home screen.

Connecting

To Your Kajeet SmartSpot

1. Make sure the Kajeet SmartSpot is powered on.
2. On your computer, tablet, mobile phone, or other Wi-Fi enabled device, select the Kajeet SmartSpot Wi-Fi network name (ex: Verizon-MiFi8800L-####) from the list of available wireless networks.
3. When prompted, type your Wi-Fi password and click OK.
4. Your device is now connected to the Internet. You will receive a verification message on the Kajeet SmartSpot that a device has connected.

To view your device's status and data usage, visit www.kajeet.com/status.
For support with your device please contact your school or district technology department.