

Kajeet SmartSpot® 6620

Quick Start Guide



The Kajeet SmartSpot® is a portable Wi-Fi hotspot that extends the school day by providing fast, filtered broadband access anywhere.



POWER BUTTON: Powers the Kajeet SmartSpot on and off and wakes the screen from sleep mode.

STATUS DISPLAY: Provides connection and battery status, network signal strength, and the number of connected users.

SELECT BUTTON: Used to select menu options.

NAVIGATION BUTTONS: Scroll left or right through the available menu options.

SMARTSPOT CHARGING PORT: The AC charger supplied with your SmartSpot connects here.

ACCESSORY CHARGING PORT: This port can be used to charge other devices via USB.



SMARTSPOT_6620_QSG_011117

Accessing

Your Kajeet SmartSpot Wi-Fi Name and Password

To access your Wi-Fi name and password follow the steps below.

1. Make sure the Kajeet SmartSpot device is powered on and is on the home screen (if the screen is off, press the power button to exit sleep mode).
2. Use the left and right arrows to navigate through the menu options until you see 'Wi-Fi Name/Password'.
3. Press the select button to display the Wi-Fi name and password.
4. When done, press the select button two more times to return to the home screen.

Connecting

To Your Kajeet SmartSpot

Once you have located the Kajeet SmartSpot Wi-Fi name and password, you can now connect to the Internet with these simple instructions.

1. Make sure the Kajeet SmartSpot device is powered on.
2. On your computer, tablet, mobile phone, or other Wi-Fi enabled device, select the Kajeet SmartSpot Wi-Fi network name (ex. Verizon-MiFi6620L-####) from the list of available wireless networks.
3. When prompted, type your Wi-Fi password and click OK.
4. Your device is now connected to the Internet. You will receive a verification message on the Kajeet SmartSpot that a device has connected.

To view your device's status and data usage, visit kajeet.com/status.

For support with your device please contact your school or district technology department.