

## Kajeet SmartSpot® T-41

# Quick Start Guide



The Kajeet SmartSpot® is a portable Wi-Fi hotspot that extends the school day by providing the fastest, filtered broadband access outside the classroom.



[www.kajeet.com](http://www.kajeet.com)



### POWER BUTTON:

Powers the Kajeet SmartSpot on and wakes the device from sleep mode.

### CHARGING PORT:

The AC charger connects here.

### STATUS DISPLAY:

Provides connection and battery status, and network signal strength.

SMARTSPOT\_T41\_QSG\_111417

# Connecting

## To Your Kajeet SmartSpot

Follow the steps below:

1. On the back of the device, note the Wi-Fi name and password on the sticker.  
**IF STICKER IS MISSING FROM DEVICE:** Remove the back battery cover, (see Fig. 1) and take note of the Wi-Fi name and password shown on the sticker. Replace back cover.
2. Hold the power button down for 3 seconds until all lights are blue.
3. On your computer, tablet, mobile phone, or other Wi-Fi enabled device, select the Kajeet SmartSpot Wi-Fi network name (ex. Alcatel LINKZONE ####) from the list of available Wi-Fi networks on your device.
4. When prompted for a password, enter the Wi-Fi password from step 1.
5. You should now be connected to the internet.




Fig. 1

To view your device's status and data usage, visit [kajeet.com/status](https://kajeet.com/status)  
For support with your device please contact your school or district technology department.