The Importance of Inspection and Maintenance

Having a state-of-the-art decanter centrifuge is no guarantee of optimum performance and efficient processes. It is just as important to have your centrifuge regularly inspected and maintained as it is to have it installed correctly.



Daily Maintenance			
Fasteners & Guards	Visually check external fasteners for looseness and guards for cracking		
Discharge Hoppers & Piping	Check for leaks		
Operations Log	Fill out normal operations log to record temperature, erratic vibration, differential speed, torque and flow rates		
Lubricator	Check level visually		
Control Panel	Check for faults and verify normal readings		
Noise & Vibration	Observe noise and vibration levels on panel		
Weekly Maintenance			
Grease Internal Bearings	See your Operations & Maintenance Manual		
Check Belt Tension			
Check Lubricant & Oil Levels			
Monthly Maintenance			
Inspection for Wear	Open top cover, remove safety covers and inspect rotor and housing for wear.		
Monitor Vibration	Verify vibration levels are at or below normal operating levels on the panel display		
Wiring, Electrical Cords, Etc.	Check for wear or damage. Replace if necessary.		
Discharge Areas	Check solids and liquid discharge areas for wear and obstruction		
Annual			
Function Check	Verify function of interlocks and system controls, check PLC battery		

Bearings & Seals		Frequency	
Main Bearings	Replace	15,000 hrs	
Internal Bearings	Replace	15,000 hrs	
Wear Components			
Feed Nozzles	Inspect for wear; replace worn nozzles if needed	· At inspection	
Discharge Nozzles	Inspect for wear; replace worn nozzles if needed		
Tiles	Inspect for wear; replace worn tiles if needed		
Feed Chamber Area	Inspect for wear; replace components if needed		
Internal Inspection of Rotor			
Remove Scroll	Inspect for wear and damaged components	15,000 hrs or 5 years maximum	
Hydraulic System			
Oil & Filter Change	Change oil and filter	4,000 hrs or twice a year	
Hydraulic Pump Unit	Inspect for leaks and damage to hoses	Monthly	
Rotodiff Hydraulic Motor or Gearbox	Inspect and change bearings and seals	15,000 hrs	
Balancing			
Bowl	Balance to specification	15,000 hrs	
Scroll	Balance to specification	15,000 hrs	

^{*}Guidelines for Centrisys municipal wastewater centrifuges. Industrial applications may vary.





