

# EQUINE BLADE & MAINTENANCE GUIDE

Keeping Animals Healthy, Happy & Beautiful™

## EARS

- 5-IN-1 Fine, Pro & Diamond Blades
- Detachable Blades #30, #40

## FACE

- 5-IN-1 Fine, Pro & Diamond Blades
- Detachable Blades #9, #10, #15

## MUZZLE

- 5-IN-1 Fine, Pro & Diamond Blades
- Detachable Blades #30, #40

## BODY

- Detachable Blades #9, #10, #10W, #15
- Lister Blades Fine, Medium & Covercote

## LEGS

- 5-IN-1 Fine, Pro & Diamond Blades
- Detachable Blades #9, #10, #15

## FETLOCKS

- 5-IN-1 Fine, Pro & Diamond Blades
- Detachable Blades #9, #10, #15



## BRIDLE PATH

- 5-IN-1 Fine, Pro & Diamond Blades
- Detachable Blades #9, #10, #15



## 5-IN-1 BLADES



FINE  
2179-301

PRO  
41884-7190

DIAMOND  
41854-7526

## DETACHABLE BLADES



#9  
2360-500

#10  
2358-500

#10W  
2377-500

#15  
2357-500

#30  
2355-500

#40  
2352-500



## LISTER BLADES



FINE  
2242-500

MEDIUM  
258-13000

COVERCOTE  
258-13080

## Tips to extend the life of your blades

Blades should always be kept clean, sharp, and well lubricated for longest life and best results.

1. Turn off and/or unplug your clippers.
2. Remove the clipper blade.
3. Remove hair by brushing away from the blade with the stiff brush provided with the clipper, or any other brush such as a toothbrush. Move cutter blade to side to expose additional areas to clean.
4. Spray the blade with Wahl Clini-Clip<sup>®</sup>, or appropriate disinfectant and follow the directions for proper sanitation. Towel dry.
5. Apply oil to the teeth to where the top and bottom blade meet, on both sides.
6. Wipe excess oil with a towel. Run the clipper for 5-10 seconds to distribute the oil properly.



BLADE OIL  
3310-230

CLINI-CLIP<sup>®</sup>  
3701