


Wiring Diagram

ROUND SOLENOID ASSEMBLY

Pierce Arrow Inc.



WIRING CHART

Connect the wires to the corresponding signs.

- A** Armature Post
- 1** Field 1
- 2** Field 2
- +** 12V


PS528C MOTOR

Use the Pierce PS534H or PS534CH Motor on the PS528C round solenoid assembly.



PS534H
Pierce 12V Motor

PS528C
ROUND SOLENOID
ASSEMBLY



PS025
SAFETY CUT OFF
SWITCH

WIRING DESCRIPTION

This chart depicts wiring from a Pierce PS528C round solenoid assembly to the Pierce PS534H or PS534CH 12V motor. Use #2 or #4 gauge wiring.



Pierce Arrow Inc.
Manufacturing recovery equipment and winches since 1976.

PRODUCT DESCRIPTION

ROUND SOLENOID ASSEMBLY

CATEGORY

WINCH PARTS

PART NUMBER

PS528C

CONTACT

Pierce Arrow Inc.
549 U.S. HWY 287 S.
Henrietta, TX 76365
www.piercearrow.us
1-800-658-6301