

How to Remove Empty Bins & Totes


Kardex Power Pick System

How To Remove Empty Bins & Totes


This article covers the most common ways to remove empty bin and totes. If the bins are not empty you will first need to follow the directions on [How to Empty Bins & Totes](#).

Remove Bins & Totes

1. Select the Bin you want removed (Multiple selection is allowed – Hold down the left mouse button and drag over Bins)



2. Hit the “Delete location(s)” button to the right of the screen



[Visit our Customer Knowledge Center for more articles like this.](#)