Mitel 6867i (Formerly Aastra)

COLOR DISPLAY

With programmable soft keys for easy access to call history, messages, settings and more.





BOTTOM SOFT KEYS

4 programmable/state-based soft keys that support up to 18 features.

LED LIGHT

Blinks when you have missed calls or voicemail.

DIRECTORY KEY

TRANSFER KEY

CONFERENCE KEY

RECENT CALLS KEY
REDIAL KEY

LINE SELECT KEYS

Toggle between lines

SPEAKER PHONE

Toggle between speaker phone and optional headset accessory.

888.336.4249 ritterbusiness.com

VOLUME

CONTROL

Mitel 6867i

ADVANCED CALL HANDLING



PARKING A CALL

Places the call on hold so it may be retrieved from another phone

- Initiate the transfer by pressing any of the available CALL PARK soft keys.
- 2. To retrieve the call, press the **CALL PARK** soft key that corresponds to the parked call you wish to retrieve.

CALL TRANSFER

- 1. Ensure you are on active call with the party you wish to transfer.
 2. If you are already connected to the transfer recipient, press the **UP** or **DOWN** navigation keys to highlight the recipient and press the soft key to complete the call transfer.
- OR If you are not connected to the transfer recipient, press the soft key, enter the recipient's number and press the DIAL soft key. At any time, press the soft key again to complete the call transfer.

VOICEMAIL SETUP

- Press the Voicemail softkey, OR dial *318 or your own phone number from your handset.
- 2. Select a PIN number.
- 3. Record your name.
- 4. Record a greeting.

TO CHECK MESSAGES

- Press the Voicemail softkey, OR dial *318 or your own phone number from your handset.
- 2. Enter **PIN** and follow prompts.

	Enable	Disable
Call Forwarding	*72 + 10 Digit Number	*73

THREE-WAY CALLING

If you are already connected to the party you wish to conference in, press the **UP** or **DOWN** navigation keys to highlight the conference target and press the harmonic soft key to complete the 3-way conference.

OR If you are not connected to the party you wish to conference in, press the the soft key, enter the conference target's number and press the DIAL soft key. At any time, press the the 3-way conference.

CALL HOLD AND RESUME

- 1. To place a call on hold, press the **HOLD** key.
- 2. To retrieve the call, press the **HOLD** key again or the **LINE** key corresponding to the line where the call is being held.

