

# COLOMBIA DVB-T 6 MHZ CHANNELS CENTER FREQUENCIES

COLOMBIA DVB-T (6 MHz) OFF-AIR TELEVISION CHANNELS / FREQUENCIES

SUGGESTED DEFAULT = 473000 kHz (473 MHz) = frequency channel 14

6 MHz Apart

Note: this is just the frequency the VeCOAX will use on the coax cable

IT IS NOT the memory position number on the TV

You can set ANY memory position number on the TV by setting the LCN as you prefer.

**EXAMPLE** Set LCN to 1, so it will go to the button number 1 on the TV remote

(frequencies in MHz)

6 MHz Apart

Channel	DVB-T FREQUENCY
2	57
3	63
4	69
5	79
6	85

VHF high-band (band III)

Channel	DVB-T FREQUENCY
7	177
8	183
9	189
10	195
11	201

12	207
13	213
UHF band	
Channel	DVB-T FREQUENCY
14	473
15	479
16	485
17	491
18	497
19	503
20	509
21	515
22	521
23	527
24	533
25	539
26	545
27	551
28	557
29	563
30	569
31	575
32	581
33	587
34	593

35	599
36	605
37	611
38	617
39	623
40	629
41	635
42	641
43	647
44	653
45	659
46	665
47	671
48	677
49	683
50	689
51	692
Channel	DVB-T FREQUENCY
52	701
53	707
54	713
55	719
56	725
57	731
58	737

59	743
60	749
61	755
62	761
63	767
64	773
65	779
66	785
67	791
68	797
69	803