

X-BATTERY MOBILE



info contacts

+ 39 02 942 1724

info@trime.it

www.trime.it

Mast & Floodlights spare parts



LED floodlight 90W

Code:
AC000_E026_036



LED 90W
upper support

Code:
LED04_C000_025ZN



LED 90W
lower support

Code:
LED04_C000_026ZN



LED floodlight 360W

Code:
AC000_E026_035



LED 360W
upper support

Code:
LED04_C000_023ZN



LED 360W
lower support

Code:
LED04_C000_024ZN




Anti-drag spacer

Code:
AS000_M023_001



Multiposition handle

Code:
AC000_M000_036



Junction box

Code:
AS000_E006_004



Coiled cable

Code:
AC000_E006_016



Mast winch

Code:
AC000_M000_084



Mast winch handle

Code:
AC000_M000_084_01



Machine level gauge

Code:
AC000_M016_002



Mast rotation lock pin

Code:
AC000_M000_003



Mast rope L.4300 mm
full eyelet / free cable

Code:
AC000_M021_009



Mast rope L.1415 mm
full / dug eyelet

Code:
AC000_M021_006



Mast rope L.1455 mm
full / dug eyelet

Code:
AC000_M021_011



Mast rope L.1460 mm
full / dug eyelet

Code:
AC000_M021_013




Pulley D.60

Code:
AC000_M021_002



Pulley D.62

Code:
AC000_M021_003



**X-BATTERY
MOBILE**

Mast & Floodlights spare parts



Pulley D.63

Code:
AC000_M021_008



Angular runner

Code:
AS000_M000_005



**Angular runner
reinforcement**

Code:
PFI08_C031_012ZN

Electrical spare parts



Battery charger gauge

Code:
AC000_E006_076



Selector

Code:
AC000_E006_041



Timer

Code:
AC000_E006_060



Lamp switch

Code:
AC000_E012_027



8 modules cover

Code:
AC000_E000_008



Green signal lamp

Code:
SI000_G006_005



Inlet plug 230V 16A

Code:
AC000_E011_005



Battery charger socket

Code:
AC000_E011_016



24Vdc 70A relay

Code:
AC000_E000_052



Battery

Code:
AC000_E000_021




Battery charger

Code:
AC000_E000_045



Battery connector

Code:
AC000_E011_015




Junction box

Code:
AS000_E006_007



Earth post

Code:
AC000_M038_035



X-BATTERY MOBILE



info contacts

☎ + 39 02 942 1724

✉ info@trime.it

🌐 www.trime.it

Chassis spare parts



Plastic enclosure door

Code:
AC000_E006_076



Handle with lock

Code:
AC000_M000_024



Door hinge

Code:
AC000_M000_009



Buffer

Code:
AC000_M024_084



Canopy handle

Code:
AC000_M000_025



Stabilizer lock pin

Code:
AC000_M000_086



Stabilizer beam

Code:
X-BOELS_C000_018ZN



Stabilizer

Code:
X-BA_G000_051



Rudder Stabilizer

Code:
X-BA_G000_052



Right mudguard

Code:
Code: X-BA_C004_050




Left mudguard

Code:
Code: X-BA_C004_049



Wheel

Code:
AC000_M000_042



www.trime.it - info@trime.it