

# Lighting Tower Specialist





#### info contacts

**4** + 39 02 942 1724

info@trime.it

www.trime.it

# Mast & Floodlights spare parts



Floodlight head

Code:

AC000\_E026\_005



Floodlight support

Code:

LED06\_C000\_09ZN



**LED Floodlight 150W** 

Code:

AC000\_E026\_015



Floodlight support

Code:

PFM07\_C000\_028ZN



Anti-drag spacer

Code:

AS000\_M023\_001



Multiposition handle

Code:

AC000\_M000\_007



Led driver power supply

Code:

AC000\_E026\_006



Led power connector

Code:

AC000\_E006\_061



Junction box

Code:

AS000 E006 004



Coiled cable

Code:

AC000\_E006\_016



**Buble level** 

Code:

AC000\_M016\_002



Mast rotation lock pin

Code:

AC000\_M000\_003



Mast winch

Code:

AC000\_M000\_084



Mast winch handle

Code:

AC000\_M000\_084\_01



Mast rope L.4300 mm full eyelet / free cable

Code:

AC000\_M021\_009



Mast rope L.1170 mm full / dug eyelet

Code:

AC000\_M021\_019



Mast rope L.1200 mm full / dug eyelet

Code:

AC000\_M021\_015



Mast rope L.1210 mm full / dug eyelet

Code:

AC000\_M021\_018



Angular runner

Code:

AS000\_M000\_005



Angular runner reinforcement

Code:

PFI08\_C031\_012ZN









4x150W LED

# Mast & Floodlights spare parts



Pulley D.58

Code:

AC000\_M021\_001



Pulley D.60

Code:

AC000\_M021\_002



Pulley D.62

Code:

AC000\_M021\_003



Pulley D.63

Code:

AC000\_M021\_008



### Electrical spare parts



RCBO 13A

Code:

AC000\_E012\_028



Lamp switch

Code:

AC000\_E012\_027



Astronomical timer

Code:

AC000\_E006\_071



Light sensor 230V

Code:

AC000\_E016\_004



Light sensor capacitor

Code:

AC000\_E000\_070



8 modules cover

Code:

AC000\_E000\_008



10 modules cover

Code:

AC000\_E000\_020



Inlet plug 230V 16A

Code:

AC000\_E011\_005



Outlet socket 230V 16A

Code:

AC000\_E011\_007



Inlet plug 230V 32A

Code:

AC000\_E011\_009



Outlet socket 230V 32A

Code: **AC000\_E011\_002** 



Outlet socket 230V 16A Shuko

Code: **AC000\_E011\_016** 



Inlet plug 110V 32A

Code:

AC000\_E011\_022



Outlet socket 110V 32A Code:

AC000\_E011\_014



Selector

Code:

AC000\_E006\_041







#### info contacts

**\** + 39 02 942 1724

info@trime.it

www.trime.it

### Electrical spare parts



Junction box

Code:

AS000\_E006\_041



Current transformer

Code:

AC000\_E006\_092



Earth post

Code:

AC000\_M038\_035

#### Chassis spare parts



Stabilizer lock pin

Code:

AC000\_M000\_086



Hinge

Code:

AC000\_M000\_055



Door rubber lock

Code:

AC000\_M000\_100



Stabilizer beam

Code:

XCHAIN C000 031ZN



Galvanized stabilizer

Code:

AS000\_M000\_048ZN



Right mudguard

Code:

XCHAIN\_C003\_026



Left mudguard

Code:

XCHAIN\_C003\_025



Wheel

Code:

AC000\_M000\_038





Lighting Tower Specialist

TRIME s.p.a.

Strada per Robecco, snc

20081 Cassinetta di Lugagnano (MI) - ITALY

Tel. +39 02 942 1724

www.trime.it - info@trime.it