

**genuine** spare parts  
fast moving items




**X-RENT**

4x1000W MH



**TRIME**

Lighting Tower Specialist



# X-RENT

4x1000W MH



info contacts

+ 39 02 942 1724

info@trime.it

www.trime.it

## Mast & Floodlights spare parts



Floodlight head

Code:  
AC000\_E026\_001



Lamp 1000W

Code:  
AC000\_E026\_018



Floodlight head glass

Code:  
AC000\_E026\_024



Floodlight upper support

Code:  
PFM08\_C000\_010ZN



Floodlight lower support

Code:  
PFM08\_C000\_049ZN



Anti-drag spacer

Code:  
AS000\_M023\_001



Multiposition handle

Code:  
AC000\_M000\_007



Lamp ignitor

Code:  
AC000\_E026\_002



Junction box

Code:  
AS000\_E006\_029



Coiled cable

Code:  
AC000\_E006\_016



Mast rope L.1460 mm full eyelet

Code:  
AC000\_M021\_005



Mast rope L.1440 mm full eyelet

Code:  
AC000\_M021\_012



Mast rope L.1440 mm full / dug eyelet

Code:  
AC000\_M021\_004



Mast rope L.1415 mm full / dug eyelet

Code:  
AC000\_M021\_006



Mast rope L.1385 mm full / dug eyelet

Code:  
AC000\_M021\_007



Hydraulic cylinder

Code:  
AS000\_I025\_001



Mast rotation lock pin

Code:  
AC000\_M000\_003



Buble level

Code:  
AC000\_M016\_002



Pulley D.60

Code:  
AC000\_M021\_002



Pulley D.63


Code:  
AC000\_M021\_008

info contacts

+ 39 02 942 1724

info@trime.it

www.trime.it



**X-RENT**

4x1000W MH

**Mast & Floodlights spare parts**



Angular runner

Code:  
AS000\_M000\_005



Angular runner reinforcement

Code:  
PFI08\_C031\_012ZN



Rubber handle

Code:  
AC000\_P037\_001

**Hydraulic unit spare parts**



Hydraulic tank cap

Code:  
AS-EC1271120



Electrovalve solenoid body

Code:  
AS-F720002B1



Electrovalve energizing coil

Code:  
AS-C150001OA



Electrovalve energizing coil plug

Code:  
AS-EC167002



250Bar valve

Code:  
AS-F733006250

**Electrical spare parts**



DSE3110 controller

Code:  
AC000\_E014\_001



Fuel level gauge

Code:  
AC000\_E015\_005



RCBO 40A

Code:  
AC000\_E012\_031



16A 2 poles C.B.

Code:  
AC000\_E012\_041



Lamp switch

Code:  
AC000\_E012\_027



8 modules cover

Code:  
AC000\_E000\_008



10 modules cover

Code:  
AC000\_E000\_008



Battery charger

Code:  
AC000\_E006\_012




Light sensor

Code:  
AC000\_E016\_002



Light sensor capacitor

Code:  
AC000\_E000\_070



# X-RENT

4x1000W MH



info contacts

+ 39 02 942 1724

info@trime.it

www.trime.it

## Electrical spare parts



Mast control buttons

Code:  
SI000\_G006\_006



1 poles switch

Code:  
SI000\_G006\_003



Generator/Mains selector

Code:  
AC000\_E006\_058



Inlet socket 230V 32A

Code:  
AC000\_E011\_009



Outlet socket 230V 32A

Code:  
AC000\_E011\_002



Inlet socket 230V 16A

Code:  
AC000\_E011\_005



Outlet socket 230V 16A

Code:  
AC000\_E011\_007



Emergency stop button

Code:  
SI000\_G006\_010



Thermal circuit breaker

Code:  
AC000\_E012\_013



12V 70A relay

Code:  
AC000\_E000\_041



12V 30A relay

Code:  
AC000\_E000\_040



Contactor switch

Code:  
AC000\_E006\_054



Fuse holder

Code:  
AC000\_E012\_030



2A fuse

Code:  
AC000\_E012\_014




Earth post

Code:  
AC000\_M038\_035



Battery

Code:  
AC000\_E000\_027



Junction box

Code:  
AS000\_E006\_002



1000W Ballast


Code:  
AC000\_E026\_012

info contacts

+ 39 02 942 1724

info@trime.it

www.trime.it



**X-RENT**

4X1000W MH

Engine spare parts



20µF capacitor

Code:  
AC000\_E000\_079



40µF capacitor

Code:  
AC000\_E000\_077



Fan belt

Code:  
K-1628297013



Air filter external element

Code:  
K-TA04093230



Air filter internal element

Code:  
K-TA04093220



Cooling Water Expansion

Code:  
K-EG66172400



Fuel filter

Code:  
K-1522143170



Fuel lift pump

Code:  
K-R140151352



Fuel pre-filter

Code:  
AC000\_M001\_008



Engine oil drain pump

Code:  
AS000\_M000\_060



Oil drain pipe kit

Code:  
AC000\_G001\_001



Anti-vibration buffer

Code:  
AC000\_M024\_054



Oil filter

Code:  
K-W21ESO1600

Chassis spare parts



Fuel tank cap

Code:  
AC000\_M000\_028



Fuel sender unit

Code:  
AC000\_E006\_082



Handle with lock

Code:  
AC000\_M000\_017




Door hinge

Code:  
AC000\_M000\_009



Door retention rope

Code:  
XECOK2\_M009\_161



# X-RENT

4x1000W MH





















info contacts


+ 39 02 942 1724

info@trime.it

www.trime.it

## Chassis spare parts

 <b>Stabilizer lock pin</b> Code: AC000_M000_086	 <b>Stabilizer beam</b> Code: XRENT_C000_151ZN	 <b>Stabilizer</b> Code: XRENT_C003_153	 <b>Pin lock with spring</b> Code: AC000_M000_077	 <b>Plastic cover</b> Code: XECO_AS009_058
 <b>Radiator cap cover</b> Code: AC000_M001_035	 <b>Radiator cap cover retention rope</b> Code: AS000_G031_083	 <b>Jockey wheel</b> Code: AC000_T003_003	 <b>AMOSS switch</b> Code: SI000_E006_009	 <b>Coiled cable &amp; electrical connector for towing</b> Code: AC000_E050_017
 <b>Trailer socket kit</b> Code: AC000_E050_016	 <b>Right mudguard</b> Code: XRENT_C004_149	 <b>Left mudguard</b> Code: XRENT_C004_148	 <b>Wheel</b> Code: AC000_T003_001	 <b>White reflector</b> Code: AC000_T013_001
 <b>Orange reflector</b> Code: AC000_T013_002	 <b>Multi-function rear right light</b> Code: AC000_E000_046	 <b>Multi-function rear left light</b> Code: AC000_E000_047		



**TRIME**

Lighting Tower **Specialist**

**TRIME** s.p.a.

Strada per Robecco, snc

20081 Cassinetta di Lugagnano (MI) - ITALY

Tel. +39 02 942 1724

[www.trime.it](http://www.trime.it) - [info@trime.it](mailto:info@trime.it)