

Thank you for choosing
Vitagoods

In the spirit of welcoming you
we would like to offer ...

**50%
OFF**

your next purchase!
Just enter this exclusive code

SMARTSPIN50

at checkout when you visit Vitagoods.com

Using Your Cleaning & Exfoliating Brush

- Wet your skin and the brush head with warm water.
- Apply cleanser to your skin or to the head of the brush.
- Push the on/off button to turn on the Perfect Skin Plus.
- Gently move the brush head in small circular motions around the area you are cleansing.
- Push the on/off button again when finished to turn off the Perfect Skin Plus.
- Use care to avoid the delicate eye area.

Note: Keep the brush head flush to your skin, using gentle pressure. Pressing too hard will impede the motion of the brush and reduce its effectiveness.

Inserting the Batteries

For maximum run time we recommend using alkaline batteries. Use one hand to hold the unit and the other hand to hold the battery cap, with your thumb at the "open" mark position pull the cap off. Insert the 4 AA batteries in alignment with the polarity symbols (+ / -) indicated on the unit. Replace the battery cap.



TWO-YEAR WARRANTY

This Vitagoods product is warranted to be free of manufacturer's defects in materials or workmanship for two years from the date of purchase. Damage or wear resulting from an accident, misuse, abuse, commercial use, or unauthorized adjustment and/or repair are not covered under this warranty.

Should this product require warranty service (or replacement at our discretion), please contact client service to obtain a Return Merchandise Authorization number (RMA) and return instructions. Proof of purchase is required. Products returned without a Vitagoods generated RMA number will not be accepted and the sender will not receive a refund, replacement, or repaired product.

Vitagoods.com

info@vitagoods.com
1.888.870.2786

There are no express warranties except as listed above. This warranty gives you specific legal rights and you may have other rights which vary from state to state.

PLEASE DO NOT RETURN THIS PRODUCT TO THE RETAILER. CONTACT US DIRECTLY FOR WARRANTY SERVICE OR REPAIR, THANK YOU.

INSTRUCTION MANUAL

Vitagoods

Perfect Skin Plus

Enhanced Cleansing & Exfoliating Brush



Your Perfect Skin Plus

The Vitagoods Perfect Skin Plus is a complete system that is safe for use in or out of the shower or bath. Inside this box you'll find everything you need for an enhanced cleansing and exfoliating experience. The Facial Brush attachments gently, yet effectively cleanse the delicate skin on your face and neck while the Pumice Stone and Body Brush attachments let you pamper and polish your entire body.

An essential tool for use in your daily skin care ritual, the Perfect Skin Plus is a professional-caliber tool that uses a gentle, rotating, micro-massage action to treat your skin to the ultimate in clean. The Perfect Skin Plus gently clears pores without harsh abrasion or chemicals. As a result your skin can better absorb the products you use. Results include a reduction in the appearance of pores, fine lines and wrinkles, and improved skin tone.

Important Safeguards and Warnings

If you are under a doctor's care for any skin condition or if you think you may have a skin condition, please consult your physician before using the Perfect Skin Plus. To ensure that you experience the full range of benefits from the Perfect Skin Plus we recommend the following:

- Do not share brush heads with anyone.
- Use with a gentle daily cleanser designed for the face.
- Do not use jagged exfoliating particles such as shells with the Perfect Skin Plus.
- If you would like to use with an exfoliating product, use one that contains soft, rounded particles.
- Using your Perfect Skin Plus to remove makeup may stain the bristles of the brush head; if discoloration occurs, clean the brush head with soap and water.
- Change your brush heads every two to three months.

Caring for Your Perfect Skin Plus

To keep your Perfecting Skin Plus in optimum condition, do not use abrasive cleaners or chemicals to clean any part of the unit. The handle is sealed and fully waterproof. However, you should not submerge any part of the Perfect Skin Plus into water.

Cleaning the Handle

- To remove any residue or buildup cleanse the handle at least once a week by removing the brush head and washing the unit thoroughly with soapy water.
- Never attempt to open the brush handle for any reason.

Cleaning the Brush Heads

- Rinse the brush heads thoroughly after every use.
- Dermatologists recommend replacing brush heads every 3 months with regular use.

Subscribe & Save Program

Replacement Head Program

To keep your Perfect Spin Plus spinning in top condition dermatologists recommend replacing your brush heads every two to three months. Our Subscribe & Save program will ensure you receive the optimal cleansing and exfoliating results without a second thought.

New brushes are available at

Vitagoods.com

Subscribe to our convenient
refill program and
Save 25% on every refill order.



Cleansing Brush

The Cleansing Brush is made of ultra-soft bristles that are specially designed for the tender skin on your face. For best results always moisten your face and the brush prior to use.



Exfoliating Brush

The hygienic, quick-drying bristles of the Exfoliating Brush are specially designed to lift away debris. For best results we recommend that you cleanse your face before exfoliating.



Pumice Stone

The Pumice Stone is designed to effectively remove calluses and dead skin from your elbows, feet and knees. Not intended for use on delicate facial skin.



Body Brush

The Body Brush extends the benefits of deep cleaning to your entire body. The larger brush head is the perfect size for deep cleaning your arms, back and legs.