

Dr. Dish Initial Setup




Unboxing the Dr. Dish

Remove staples on bottom of box




 \mathbf{Z}_{\bullet} Lift box up and over the Dr. Dish




- A. Cut plastic ties and remove Shots

 Made Counter (Pro and All-Star models only)
 - **B.** Remove plastic bags, cut remaining plastic ties and remove plastic wrap from net poles.




4. Lift the Dr. Dish up (2 people required!) and move to the edge of the pallet in order to install front casters.




Unboxing the Dr. Dish cont.


5. Install the Casters using a 3/4in wrench (not included) on the underside of the caster and 9/16" wrench (not included) on the nut. Repeat to the other side of the Dr. Dish.



When casters are installed and tight, remove the Dr. Dish from the Pallet.




Included with the Dr. Dish



Shots made Counter parts


Shots Made Counter Head

(Pro and All-Star Model only)





Shots Made Counter Handle

(Pro & All-Star Model only)



Dr. Dish Assembly





from the factory