



# Link-Belt 218 HSL Desktop Simulator Configuration



**Horn | Select  
Button**

**Swing Lever**  
Forward = Swing Right  
Backward = Swing Left

**Boom Lever**  
Forward = Boom Down  
Backward = Boom Up

**Main Hoist Lever**  
Forward = Hoist Down  
Backward = Hoist Up

**Auxiliary Hoist Lever**  
Forward = Hoist Down  
Backward = Hoist Up