

10B Timber Lane, Marlboro, NJ 07746 • (732) 780-5300 • FAX: (732) 294-0001 • www.tandcplastics.com

Servicing

- 1. Remove cleanout and empty any material that may be in there on a regular basis to ensure proper function of cartridge(When reinstalling plug to clean out, add more Teflon tape to ensure proper a proper seal)
- 2. Ensure inlet and outlet pipes are clear and working probably

Cartridge Cleaning

- 1. Disconnect inlet and outlet connections
- 2. Remove housing for inlet and outlet
- 3. Take siphon tube and pail that came with cartridge, insert in center of cartridge to remove remaining liquid
- 4. Empty remaining granular media limestone chips that remain in cartridge by holding upside down and emptying into separate container or pail that came with unit
- 5. Dispose of any material per state laws

Cartridge Servicing

- 1. Plug the center tube inside the cartridge
- 2. Add **NEW** media limestone chips to fill up cartridge
 - a. Plug internal stand pipe so no limestone chips go inside (If media limestone chips fall in the internal stand pipe, remove clean out on bottom and remove any material. If this happens be sure to reapply teflon tape.)
 - b. **DO NOT** fill past height of internal stand pipe
 - c. FILL ¾ of an inch below height of internal stand pipe

Reconnecting

- 1. Make sure threads to inlet and outlet housing are clean with no material on threads
- 2. Reattaching housing for inlet and outlet
- 3. Reconnect inlet and outlet