



# Getting Started with AccuroFit

## ACCURO ONBOARDING

Onboarding is your chance to get familiar with your new display system. Our team will guide you through the installation, operation, and introduce you to all the features available with your system.

*To schedule your Accuro onboarding, please call or email us with your availability.*

877-409-0937

[Support@accurofit.com](mailto:Support@accurofit.com)

## INSTALLATION GUIDE

### ➤ STEP #1 – Router Setup

- Unpackage everything from the box that was shipped to you. Locate the NETGEAR Router.
- Plug the NETGEAR router into a power source.
- Decide if you will connect the NETGEAR Router to the laptop or the studio router.
- The NETGEAR router needs to be less than 100 feet (recommended less than 75 feet) away from the Accurofit receivers if you are connecting the router to the laptop.

### IF CONNECTING TO STUDIO ROUTER FOLLOW THESE INSTRUCTIONS

- Take the ethernet cord and plug it into the BLUE port on the back of the NETGEAR router that we sent to you.
- Plug the other end of the ethernet cord into an open numbered port on the back of your in-club router that you utilize for internet access. After a few seconds, you should see all solid green lights on the front of the router.

### IF CONNECTING TO THE LAPTOP FOLLOW THESE INSTRUCTIONS

- Take the ethernet cord and plug it into one of the open BLACK ports of the NETGEAR router that we sent to you.
- Plug the other end into the laptop. After a few seconds, you should see all solid green lights on the front of the router.

### ➤ STEP #2 Receiver Setup

- Locate the receivers from the box that we sent to you. They are small, have a white button and two little lights on the front of them.
- Locate the area/ room you are looking to cover with the heart rate projection. (Remember: each receiver covers about 1,000 square feet)
- Once in the space, locate an outlet on one side of the room. The higher the outlet is, the better. If the outlet is high up on the wall, this would work best.
- Plug one receiver into the outlet. The receiver should automatically turn on.

**For More Assistance or Questions, please contact AccuroFit Support: 877-409-0937**

- On the opposite side of the room, locate a second outlet. Again, the higher up the wall, the better.
- Plug in the second receiver into the outlet. The receiver should automatically turn on.
- If you have more than 2 receivers and are looking to cover more space, the same process can be repeated as above.

*For best performance, make sure the receivers are within 100 feet of the router.*

#### ➤ **STEP#3 – Laptop Setup**

- Locate the space you want to keep your Laptop. If it is in the same room that is being covered, that typically works best. If it is another area, please locate that, but make sure you have access to HDMI and the TV you are looking to connect to.
- Plug the Laptop into an outlet.
- Connect the Laptop to your TV via an HDMI cable.
- Turn the Laptop on.
- Once the Laptop powers on, it should automatically connect to the Netgear router we provided and that you have already set-up.

#### ➤ **STEP#4 – Check System Status**

- Open the AccuroFit Software.
- On the left-hand side, select "Admin Panel".
- Select "Wireless Receivers".
- Make sure you see your receivers listed there. If you do not, please contact our support team at: 877-409-0937

#### ➤ **Step#5 – Display Setup**

- Close the AccuroFit Software.
- Right click on the desktop.
- Select "Display Settings"
- On the right-hand side, scroll down until you see "Multiple Displays".
- The drop-down will be defaulted to "Duplicate This Display".
- Change the drop-down to "Extend This Display".
- Select Save/ Keep these changes.
- Re-open the AccuroFit Software
- Select "Class Session".
- Click "Show Display"
- The heart rate display should now be on your TV display. The Laptop display will remain on the software controls. This allows you to continue to add new profiles, modify profiles, etc. without interrupting a class session that might be taking place on the TV screen.