

INTRODUCTION

The PD108-207 remote control provides patient control of the model PDI-Z9TV, nine-inch support arm television and the PDI-13TV, thirteen inch support arm television. This remote will also control additional television brands. See the accompanying owner's manual for a complete listing of compatible codes. The instructions assume you have correctly installed two "AAA" batteries.

SETUP CODE



REMOTE PROGRAMMING

1. Press and hold the Code Search button until the red indicator stays on. Release the Code Search button. The red indicator blinks and then stays lit.
2. For a 9 inch TV, enter the three-digit code **405**. For a 13 inch TV, enter one of two codes: 115, or 713. Note: after a valid code entry, the red indicator turns off. For an invalid code entry, the red indicator flashes.
3. With the TV turned ON, press CHANNEL UP. If the TV responds, no further programming is required.

BED A and BED B PROGRAMMING (Nine Inch TV ONLY)

To use a second remote in a two-bed (two TV) hospital room, special programming instructions must be followed. The first step involves programming the nine-inch support arm TV to respond to a different remote control code. The second step involves programming the PD108-207 to that second IR control code different than code 405.

PROGRAM THE TV

1. Turn the BED B TV ON. Using a second different remote control, the PD108-206 programmer's remote (hint: this remote has a MENU and ADJ buttons), enter the hidden factory service menu. Press and hold the MENU button on the remote control until the TV's on-screen users menu disappears.
2. Quickly enter the numbers 9876 on the remote. Then press ENTER on the remote. A hidden factory service menu will appear on the TV's screen. Use the programming remote control's SELECT UP/DOWN keys to toggle through all of the menu items. Use the ADJUST key to make a change to the selected item.
3. Use the SELECT keys on the programmers remote and choose item 1 FACT MODE. Set this item to 1 (ON) to expose additional factory menu items.
4. Use SELECT keys on the programmers remote and choose item 52 ZEN/PL. When the TV is set to 0 (OFF) the TV will respond to normal Zenith IR codes. Set the item to 1 (ON). The TV will now respond to a PL or (private label) remote control code.
5. Use the SELECT keys on the programmers remote and choose item 1 FACT MODE again. Set this item to 0 (OFF). If the factor mode is left ON (set to 1) the TV will not turn OFF or channel up or down.
6. Now press ENTER on the programmers remote to exit the factory menu.

PROGRAM THE BED B PATIENT REMOTE

1. Press and hold the Code Search button until the red indicator stays on. Release the Code Search button. The red indicator blinks and then stays lit.
2. Enter the three-digit code **701**. Note: after a valid code entry, the red indicator turns off. For an invalid code entry, the red indicator flashes.
3. With the TV turned ON, press CHANNEL UP. If the TV responds, no further programming is required. Now the BED B TV will respond to a second remote without interference to the BED A TV.

NOTE: The BED B TV will no longer respond to standard Zenith IR control codes. To reprogram the TV you will need to use a programmer's remote with the IR code set to code 701.