

Mounting the iMR in a Rack (CS-iMR-RMK)

Assemble Equipment

If you decide to mount the CS-iMR in a <u>rack</u>, you will need to order a rack mount kit (CS-iMR-RMK) so you have the proper equipment/supplies to mount the iMR in a rack.



Models herein and their appearance are subject to change without any prior notice.

Remove and inventory all contents from the additional CS-iMR-RMK packaging, including:

- 1 pc- Left Mounting Bracket
- 1 pc- Right Mounting Bracket
- 1 pc- Front Panel

1 pc- Shim
12 pcs- 6-32 x ¹⁄₂" black screws (2 extra screws included
5 pcs- 10-32 x ³⁄₄" black Rack mounting screws

(1 extra screw included)

Procedure – Connect the CS-iMR in a Typical Central Rack



PLEASE READ ALL INSTRUCTIONS BEFORE ATTEMPTING TO INSTALL EQUIPMENT. FAILURE TO FOLLOW DIRECTIONS CAN CAUSE BODILY INJURY AND/OR DAMAGE TO EQUIPMENT.

- a. Place CS-iMR unit on a scratchproof surface, upside down so the text at the back of the unit is right side up.
- b. <u>Remove three screws on each side of iMR</u>, (sides with venting/no connections), and discard those screws.
- c. Then, remove two screws from each side, approximately in the center of the unit, and discard those screws.
- d. Place the "Front panel" ((A)) over the front of the iMR unit matching up the three screw holes on the side.
- e. Mount the front part of both of the mounting ear brackets (G) to the front part of the unit through the front panel (A) using six of the 1/2" black screws.

Then, use two 1/2" black screws on each side (total of 4 screws) and mount the back end of the mounting ears through the shims (¹) into both sides of the iMR device.

NOTE: Align the shims so they line up even with the top of the chassis. Ensure that all screws are tightened.

f. Install CS-iMR unit into the rack using the supplied 10-32 x ³/₄" black rack mounting screws. U It is required that there be at least a 1U spacing (1.75") above and below this unit when mounting it. () Important

It is required that there be at least a 1U spacing (1.75") above and below this unit when using rack mounting kit.

Front bracket for CS-iMR



Attach side ear brackets with screws

