

Lubrication for a Noisy Martindale – Martindale 900 Series

WARNING: Any maintenance work undertaken on a James Heal instrument must be done so by a trained and competent person. Where electrical work is detailed, this should only be completed by a qualified engineer. James Heal is not responsible for damage or injury arising from work carried out by any person not qualified to do so. If in doubt, please contact James Heal or your local James Heal Agent.

Recommended greases are Kluberfood NH1 94-6000, or, Kluber Isoflex LDS 18 Special Grease

1. Remove old grease from the drive slots.
2. Check the surface of the top plate slots for wear or burrs.
3. Apply a thin smear of grease to all faces of the slots.
4. Check there is no wear to the bearing pad running area.
Clean this area and apply a thin smear of grease to prevent noise during operation.
5. Remove the drive pins, clean off the old grease and apply a small amount of new grease to the pin and also the outer surface of the bush.

