



Heating graphite susceptor for glass reflow for X-ray tubes

Objective Heat graphite susceptor for glass reflow in the manufacturing of x-ray tubes

Material Glass disc 0.98 x 0.12 " (25 x 3mm), graphite susceptor, stainless steel holder, Glass bell jar 5.9" (150mm) OD

Temperature 1742 °F (950° C)

Frequency 84 kHz

Equipment

- Ambrell 15 kW induction heating system, equipped with a remote workhead containing eight 0.3 µF capacitors for a total of 2.4 µF
- An induction heating coil designed and developed specifically for this application.

Process A two turn helical coil is used for heating. Six graphite susceptors are placed in the nitrogen atmosphere with glass discs and a stainless steel holder. In 32 seconds the required temperature of 1742 °F (950° C) is reached causing the glass to reflow & the stainless steel holder to melt through the glass.

Results/Benefits Induction heating provides:


- Increased production, customer currently heating 4 susceptors
- 50% lower energy consumption
- Even distribution of heating




AMERITHERM FRANCE

Precision Induction Heating

AN AMBRELL COMPANY



Susceptor with glass
before heating



Susceptor after heating




Susceptors being heated
in Nitrogen atmosphere



Placement of susceptors
showing uniform heat pattern

Bottom of X-ray tube



Ameritherm Inc.
www.ameritherm.com
001.585.889.9000

 **Ambrell Companies**
Cheltenham Induction Heating, Ltd.
www.cihinduction.com
00 44 (0)1242 514042

Ameritherm France SARL
www.amerithermfrance.com
+33 (0)3 89 76 01 24

heating_41.doc | © 2008 All information subject to change without notice