

GyroWash - High Temperature ($\geq 60^{\circ}\text{C}$) Small Pot Lid Instructions



1. Secure the high temperature small pot lid (528-126) onto the pot by twisting clockwise using the pot lid spanner.



2. Tighten the pressure valve on the lid by turning clockwise using the tool on the pot lid spanner (528-128).



3. Clamp down the lid clip.



4. Insert the pot into the GyroWash arbour and lock into place by twisting clockwise. Close the lid and start the test.



5. When the test is complete, whilst wearing gloves remove the pot from GyroWash by twisting anti-clockwise & lift out.



6. If required, cool briefly in cold water. Secure in the jig (528-124) by twisting clockwise, then unclip.



7. Unlock the valve by turning it anti-clockwise using the tool on the pot lid spanner.



8. Release the lid by twisting anti-clockwise using the pot lid spanner, then lift from the pot with a gloved hand.