

Class 100 Fiber-Free Face Masks

cleaning critical surfaces



Description

Foamtec 4400 Series, Fiber-Free Face Masks provide continuous particle/moisture control and cool, flexible comfort without the speech constraints, goggle/glasses steaming or moisture build-up on the face typical of paper and dense cloth masks. Foamtec Face Masks are used as comfortable under-masks for hoods with built-in biological masking. They protect the wearer from contact and provide a fresh, clean barrier to the laundered mask in the hood.

Advantages

- Particle/moisture control restricts vapor transfer from breath to work surface
- Cool comfort even during strenuous production and maintenance procedures
- Comfortable as under-mask protection for attachable hood veils
- No restriction of breath or speech clarity; reduces lifting or pulling down masks
- Will not fog safety goggles
- More absorbent for greater particle control and longer life
- Absolutely fiber-free

Part Numbers

Product Models Available

| | | | |
|--------|-----------------|--------|-----------|
| HT4401 | Foam Face Mask | 10/bag | 2500/case |
| HT4402 | Foam Beard Mask | 10/bag | 2000/case |

Cleanliness

| | | |
|--|---------------------|----------------------|
| Particles | > .5 μ Via LPC* | <750/cm ² |
| TNVR's | DI H ₂ O | <.9g/m ² |
| Ions - count of extractable (PPM) | | |
| Chloride | <5 | |
| Sodium | <15 | |
| Potassium | <2 | |

* *Liquidborne Particle Counts*

Methods of Use

Foamtec International Face Masks should be stored in a clean donning area away from fumes and removed from packaging only for immediate donning. Crush the ear-holds in each closed fist and stretch the mask by pulling your hands slightly apart. Pull each ear-hole over corresponding ear and place mask over nose and under chin so it fits snug against your face.