



SM INSTRUCTIONS



Turn On

Press and hold the power button on the right-hand side of the unit. You will hear the welcome message 'Sensear, Sounds Good To Me'. The green light on the right hand side of the unit will begin to flash slowly. You are in SENS Mode – Speech Enhancement Noise Suppression.

Turn Off

Press and hold the power button on the right-hand side of the unit. You will hear the message 'System Shutting Down'.

Adjusting The Volume

Press the plus (+) or minus (-) sign button on the right-hand side of the unit. For the highest volume continue to press the plus (+) button until you hear 'maximum'. The unit limits ear noise exposure to 82dB(A).

Switching Modes

To switch between SENS and passive or quiet mode press the power button once you have turned on the unit. The green light on the right hand side of the unit will flash intermitently in SENS mode and quickly in passive or quiet mode.