Case Study: Sodium Azide Assessment

New England Healthcare Provider

Situation

The hemotology equipment within a New England hospital lab was **discharging a sodium azide solution into laboratory cup sinks** as part of routine operations. **During a repair** to a cup sink's cracked and leaking ptrap, **an explosion occurred.** The sodium azide waste had come into contact with brass and copper plumbing, forming and accumulating explosive, shock-sensitive metal azides.

Action

Triumvirate entered as a **remedial contractor and health & safety consultant**. Here's how we took care of the problem :

- Identified **six sinks** exhibiting the potential for metal azide contamination. All **required immediate remediation**.
- Isolated the affected area, turned off sink operations, and installed localized ventilation, all in level-C personal protective equipment
- Plugged exposed piping
- Performed remediation by chemical rinse with a sodium hydroxide solution, remaining on-site for the 16-hour rinse duration to monitor air quality, observe liquid levels, and monitor for leaks.
- Performed a **second chemical rinse** after rinsing drains with cold water. This time nitrous acid solution for 24 hours.
- Removed the spent liquid for both chemical rinses using tubing and a vacuum, consolidated it into 30-gallon DOT drums, and removed off-site.
- Performed a visual inspection of the copper and brass fittings and then removed the metal fittings and screened the remaining cast iron pipe. The pipe was managed as scrap metal.



TRIUMVIRATE Environmental

Result

Triumvirate **removed the immediate explosion hazard** by neutralizing any metal azide within the piping and **limited the long-term potential for accumulation** of metal azide in lab plumping by removing all metal piping. **Metal-free**

piping and fixtures were installed, and **wastewater volumes and flows were closely monitored** from this point on to prevent signifiant accumulation of explosive metal azides in plumbing. As a preventative measure for the future, Triumvirate's technical team **advised the hospital to use azide-free reagents** in their wastewater process or to containerize sodium azide wastewater for disposal.



Craig Sasse, LSP Technical Manager 774-836-5637 CSasse@triumvirate.com