

CUBISCAN 110 RENTAL RETURN INSTRUCTIONS

BOXING UP THE UNIT

Begin boxing up the unit

- Unplug the sensor cables from the three sensors and pull cables through the holes they come from on the back of the unit (images 2 & 3)
- Tilt the unit on its back and loosen the shipping bolts to touch the pads in the frame (images 1 & 4)
 - Do not loosen too much, they only need to barely touch the pads
- Tighten the five feet beneath the unit
- Tie the sensor cables to the inside of the frame with twist ties
- Tie the power supply and USB cable to the inside of the frame with twist ties
- Place unit back on its feet and remove the four bolts that hold on the back plate, tilt the back plate down onto the unit and screw the bolts back into the unit (image 5)
- Wrap the top sensor with bubble wrap or foam (image 6)



Place the unit into the crate

- Place two pieces of foam behind the unit, one on each side, and one covering the display (image 6)
- Screw in the 2x4 in front of the display to secure the unit into the crate (image 6)



Place the box of components into the crate

- Power cord
- Calibration cube
- Level bubble
- Communication cable
- 2.5mm allen wrench
- 4.0mm allen wrench
- 5.0mm allen wrench
- 6.0mm allen wrench
- 1/8" allen wrench
- USB to serial cable
- Open-end wrench
- USB cable
- Tare strips (3 bent, 1 flat)



Put on the lid

