CUBISCAN 150 RENTAL RETURN INSTRUCTIONS

BOXING UP THE UNIT

Begin boxing up the unit

- Unplug the height sensor cable from the tan connector on the back of the unit, and undo the four black bolts that hold on the overhead arm
- Remove the overhead arm and wrap in bubble wrap or foam, set aside for later, once removed, screw the four black bolts back into place (image 2)
- Tighten the four shipping bolts up into the black scale base (image 3)
 - Begin by threading the bolt up into the black scale base about 1/4 of an inch
 - Then lower the top nut so that the scale lifts off of the load cells about $1/8^{\prime\prime},$ no more
 - Once the scale is lifted, tighten the bottom nut to secure the bolt into place

Place the unit on the crate base onto the two beams with foam on top

- Be sure the unit is placed on the beams correctly, or the unit will sit out too far resulting in the side panels hitting the unit

Make sure the two black shipping clamps are properly installed on the frame in opposite corners

- They should have a piece of cardboard between the clamp and the unit
- There should be two long bolts and two nuts for each clamp
- Make sure the clamps are tightened so the unit will not move from the base

801.451.7000

info@cubiscan.com

Strap in the overhead arm to the crate base near the back of the unit

Place the box of components in the crate in front of the unit

- Power cord
- Calibration cube
- 5/64" allen wrench
- Communication cable
- 1/8" allen wrench
- 7/64" allen wrench
- 9/16" allen wrench
- USB to serial cable
- USB cable

Put the four sides and lid onto the crate









Image 3

