

**HOW DO I START MY SHIFT?**



**A: Press the power button and wait for the solid green light**  
 Press once firmly on the power button on G7. When the SureSafe™ light is solid green, you are safe to start working.

**WHY IS G7 FLASHING GREEN?**



**A: You have lost connection to the Blackline Safety Network**  
 Your safety is not being monitored, only when the SureSafe light is solid green is it safe to work.

**HOW DO I CALL FOR HELP?**



**A: Pull the red latch if you require assistance**  
 Your device will alert monitoring personnel.

**WHY IS G7 BLINKING YELLOW?**



**A: Your device is asking you to confirm that you are OK**  
 Press the latch once to check-in and silence the beeping. If you are unsure why G7 is in yellow pending alarm, you can read the screen for clarification.

**WHY IS G7 RAPIDLY BLINKING YELLOW?**



**A: G7 Has a message for you.**  
 Read your G7 Screen, it has a message that could be an incoming text message, voice call, network connection interruption, low battery, or a warning alarm regarding gases or sensors.  
 To silence this alarm, press and hold the up and down arrows for three beep cycles.

**WHY IS G7 RAPIDLY BLINKING RED?**



**A: G7 has communicated to monitoring personnel**  
 G7 has immediately communicated a red alert to monitoring personnel. If you are unsure why G7 is in red alert, you can read the screen for clarification.  
 To silence this alarm, press and hold the up and down arrows for three beep cycles. This will not cancel the alert communicated to monitoring personnel.

**WHY IS G7 FLASHING BLUE?**



**A: Monitoring personnel have received your remote alert, and are responding by following your emergency protocol**  
 No action is required from you. Monitoring personnel will be contacting you via two-way voice (if enabled) or text message to ensure you are OK. Once monitoring personnel have resolved your alert, the LiveResponse blue light will shut off.

**HOW DO I BUMP OR CALIBRATE?**



**A: Use the up and down arrows to navigate to bump test or calibrate from the main menu**  
 From there, follow the instructions on G7 screen.

**HOW DO I END MY SHIFT?**



**A: Press and hold the power button**  
 Press and hold the power button on G7. The device will go into the shut down sequence. When the SureSafe light is off, you have been successfully logged off the Blackline Safety Network and your safety is no longer being monitored.  
**Charge after every shift**  
 Always charge G7 after every shift, and leave charging when not in use.