



How to replace G7's cartridge:

1. Power off G7
2. Using a Phillips #1 screwdriver, remove the screws on each side of the cartridge
3. Pull up on the cartridge
4. Slide a new cartridge onto G7, ensuring the cartridge clicks into place
5. Replace screws on each side of G7

NOTE: Cartridges should always be replaced with a manual (not electric) screwdriver in order to avoid damage to the device's plastics.

LEARN MORE

Visit support.BlacklineSafety.com for more information on G7 cartridges and devices.

CUSTOMER CARE

For technical support, please contact our Customer Care team.

North America (24 hours)

Toll Free: 1-877-869-7212

support@blacklinesafety.com

United Kingdom (8am-5pm GMT)

+44 1787 222684

eusupport@blacklinesafety.com

International (24 hours)

+1-403-451-0327

support@blacklinesafety.com