## () IMPORTANT! G7X NEEDS TO BE PAIRED



Before the G7x in this box can be used, it will first need to be paired to a your organization's Bridge network. Pairing devices is a one-time setup step. After being paired, G7x and any Bridge in your organization will automatically connect to one another when on and in range.

## Before getting started you will need:

- G7 Bridge with a solid green light
- G7x devices you wish to pair



## How do I pair new G7x devices with my organization's Bridge network?

G7x will let you know it needs to be paired by sounding a yellow warning alarm and by showing *pairing needed* in the banner. To pair:

- 1. Turn on G7 Bridge
- 2. Press OK on G7 Bridge to open Bridge's menu
- 3. Use the up and down arrows to navigate to *pair new loners* and press OK
- 4. Use the up and down arrows to navigate to *start* and press OK NOTE: if your G7 Bridge will not allow you to start pairing, this means it has not yet been assigned a network key for your organization. Please contact our Customer Care team.
- 5. G7 Bridge's screen will say pairing started as it looks for devices
- 6. Turn on up to 5 G7x devices.
- **NOTE:** G7 Bridge can only connect to 5 G7x devices at once.
- 7. When G7x has been paired, you will notice the following:
  - G7 Bridge's main screen will show that it has connected devices
  - The yellow warning alarm on G7x will silence
  - G7x's green connectivity light will be solid (not flashing)
  - You will receive a message on G7's screen that reads *pairing succeeded* and shows your organization's Bridge network key
- 8. Press OK on G7 Bridge to stop pairing once all necessary devices have been paired
- If you are pairing more than 5 G7x devices, repeat steps 2-7 for all G7x devices.

## If you are having difficulties pairing, you can try the following:

- Ensure that G7 Bridge has a solid connectivity light
- Place G7x and Bridge within 1-3 meters of one another. If devices are too close, they may have difficulties connecting.
- Ensure you aren't trying to pair more than 5 G7x devices at once. G7 Bridge can only connect to 5 G7x devices at a time.

Need support? Our Customer Care team has your back.

North America (24 hours) Toll Free: 1-877-869-7212 support@blacklinesafety.com United Kingdom (8am-5pm GMT) +44 1787 222684 eusupport@blacklinesafety.com International (24 hours) +1-403-451-0327 support@blacklinesafety.com