



TOWN & COUNTRY PLASTICS

Customized For Precision

10B Timber Lane, Marlboro, NJ 07746 • (732) 780-5300 • FAX: (732) 294-0001 • www.tandcplastics.com

Model #PP-41A, #PP-41AP,
#PP-39AP and #PP-40AM

INSTALLATION BULLETIN

**USE RECOMMENDED MASTIC FOR INSTALLING THE
(SO3-R) SINK OUTLET IN SINKS**

1. Scuff the contact surface under the outlet flange with sand paper to increase adhesion.
2. Clean both the outlet and the recessed hole in the sink with lacquer thinner or like solvent.
3. Apply recommended RTV Silicone to outlet in a ¼" bead around the bottom edge.
4. Insert outlet directly into the recessed hole in sink.
5. Give the outlet a ¼ turn after you make contact.
6. From under the sink, thread the retaining nut all the way up and carefully hand tighten until the upper outlet flange is flush with the sink basin. (Do not use tools or over tighten the plastic retaining nut.)
7. Wipe off the excess adhesive in the sink.

T&C OFFERS POLYPROPYLENE TAILPIECES AND/OR TRAPS, AT EXTRA COST.