

# CUBISCAN 100 RENTAL RETURN INSTRUCTIONS

## BOXING UP THE UNIT

Begin boxing up the unit by removing the side panels and sensors (image 1)

- Put side panels in the bottom box with foam inbetween the panels (image 2)
- Put the top plate & sound deadening plate into the cardboard sleeve and tape it shut (image 3)
- Place top plate into box on top of side panels (image 4)
  - Be careful not to place the top plate directly onto the pems on the side panels as they might break off during shipping
- Unplug the sensor cables and tie to the inside of the frame with twist ties (image 5)
- Tie the power supply and USB cable to the inside of the frame with twist ties (image 5)
- Tighten the five feet beneath the unit so it fits in the box better (image 6)
- Screw in the three shipping bolts (image 7)
  - Do not over tighten, they only need to barely touch the pads

Place the foam insert into the box with the components on the opposite side where the top plate was placed (image 6)

- Power cord
- Calibration cube
- Communication cable
- 2.5mm allen wrench
- 4.0mm allen wrench
- 5.0mm allen wrench
- 6.0mm allen wrench
- USB to serial cable
- USB cable
- Tare strips

Place the unit into the box and put on the lid (image 6)



Image 1




Image 2



Image 3



Image 4



Image 5



Image 6




Image 7

