

# CUBISCAN 25 RENTAL RETURN INSTRUCTIONS

## BOXING UP THE UNIT

Place the two foam inserts into the box with the components placed in the foam slots (image 1)

- Power cord
- Communication cable
- USB to serial cable
- Small calibration cube
- Glass box containing two pieces of glass
- Ethernet cable




Box up the glass (image 2)

- There should be two pieces of glass
- Reuse the shipping materials that the glass was sent in, repackage and set aside to eventually be placed into the cardboard/foam gate cover (image 2)


Begin boxing up the unit (images 1, 3, 4, 5)

- Place the two green foam inserts into the box with the components (image 1)
- Place the four green foam squares beneath each corner of the scale (image 3)
- Tighten the four scale bolts on either side of the scale (images 4 & 5)



Place the unit into the box in line with the two foam inserts (images 1, 2, 6)

- Put the cardboard/foam gate cover over the unit into place (image 1)
- Secure the gate into place by tightening the gate stop (image 6)
- Put the glass box into the gate cover and fold the flaps down to secure it to the cover (image 2)
- Tape the box closed and place the box onto a pallet for shipping



Secure box to pallet with straps and wrap

