

CUBISCAN 75-C QBIT-XFER SETUP

QUICK REFERENCE GUIDE

This quick reference guide provides instructions for setting up Qbit-Xfer to connect to a Cubiscan 75-C. For more detailed instructions, see the *Qbit-Xfer User Guide*.

- 1 > Make sure that Qbit-Xfer is installed on your computer.
- 2 > Connect your computer to the Cubiscan. See the "Cubiscan 75-C Ethernet Setup Quick Reference Guide."
- 3 > Open Qbit-Xfer and select **Tools > Options**. Make sure the Cubiscan tab is selected.
- 4 > Select the **Cubiscan 75** as your Cubiscan model.
- 5 > Enter the default IP Address of **10.1.100.100** and the default IP Port setting of **1050**.
- 6 > Enable the **Send Network "Heartbeat"** radio button. Enter an interval of **30**.

- 7 > When you are finished, click **OK**.

Your Cubiscan should now be connected to Qbit-Xfer.

