

# MolokDomino® Light installation instructions



MolokDomino® Light is installed on an even, hard ground in a way that the filling lid faces the user.

1. Remove plastic covers that protects the containers during transportation.
2. Remove the blue lifting loops that were used to lift the containers on site.
3. Open and straighten the lifting bag before placing it in the container. Check that the bottom of the lifting bag is closed tightly and the rope is placed according to the instructions. It is possible for the lifting bag's closing mechanism to open during delivery. If the container is divided in to two sections, check both lifting bags.




4. Place the lids, lifting bags and quick systems on their place. If the lid is not fastened to the quick system; fasten the lid with M8 x 35 torx screws. There are 3 screws per lid. Cover plate is used on the hole of the lifting handle: fasten the cover plate with screws.
5. Clean the surrounding area of installation material.

If needed, sand sacks or concrete blocks etc. can be placed inside the container, next to the container wall for extra weight. The containers can also be bolted on ground for stability. The method for fastening must always be selected according to the installation site.

## When installing the containers into a group

Leave 40 mm distance between the tops of the wells and attach the adjacent containers with an upper rail. The rail is drilled through the support frame and fastened from 8 points with pop rivets.

Finish the framings by fastening extension pieces for framing (A+B) with pop rivets, see image on the right. First fasten the lower horizontal support profile (B) in line with the framing element. Place the vertical extension piece (A) on correct place between the two framing elements and fasten the upper horizontal support profile (B). Finish the framing by fastening the vertical extension piece (A) to the horizontal support profiles (B). Make sure the vertical extension piece is installed straight.



Finishing the framing

DEEP COLLECTION®