



**FIELD FASTENING**

1. FASTEN SIDE LAPS (THROUGH BOTH SHEETS) AT 9 IN. O.C.
2. INSTALL 2 EQUALLY SPACED ROWS OF FASTENERS STAGGERED BETWEEN EACH ROW AT 18 IN. O.C.




**PERIMETER FASTENING**

1. FASTEN SIDE LAPS (THROUGH BOTH SHEETS) AT 6 IN. O.C.
2. INSTALL 2 EQUALLY SPACED ROWS OF FASTENERS STAGGERED BETWEEN EACH ROW AT 9 IN. O.C. WITHIN THE SPECIFIED WIDTH OF ALL EXTERIOR PERIMETERS.




**NOTES:**

- A. MAINTAIN 3" MIN. SIDE LAPS.
- B. MAINTAIN 6" MIN. END LAPS.
- C. END LAPS SHALL BE OFFSET AND STAGGERED 36" MIN.
- D. INTERMEDIATE ROW FASTENING IN THE FIELD OF THE BASE SHEET SHALL BE EVENLY STAGGERED.



**CORNER FASTENING (IF REQUIRED)**

1. FASTEN SIDE LAPS (THROUGH BOTH SHEETS) AT 7 IN. O.C.
2. INSTALL 3 EQUALLY SPACED ROWS OF FASTENERS STAGGERED BETWEEN EACH ROW AT 7 IN. O.C. WITHIN A SPECIFIED CORNER AREA.



GENERAL REFERENCE:  
"FTR GS 01/21"

APPLICABLE SYSTEMS:  
"FTR MA 01/21"  
"FTR AD 01/21"

**FTR SBS BASE SHEET ATTACHMENT**

REVISES DETAIL

ALL PREVIOUS

ISSUE DATE

01-22-25

DRAWING NUMBER

FTR-DM2a