



ENCLOSURES DESIGNED FOR THE WORLD'S WATER SYSTEMS™

## ASSEMBLY INSTRUCTION READ CAREFULLY




FIG. 1C




FIG. 1




FIG. 1A





FIG. 1B

Model No.	Inside Dimensions	Outside Dimensions	Recommended Concrete Pad Dimensions
300D-Series	48"W x 78"L x 44"H	51"W x 81"L x 47"H	65"W x 95"L x 6" Thick
300TD-Series	48"W x 78"L x 50"H	51"W x 81"L x 53"H	65"W x 95"L x 6" Thick

1. Center a "6" thick concrete base around installed BFP.
  - A. Place expansion material around riser pipes and place conduit for electrical power before placing concrete. **CONCRETE SHOULD BE FINISHED ABSOLUTELY LEVEL, FLAT AND SMOOTH.** Allow concrete to cure.
  - B. Mark concrete with outside dimensions of enclosure. (Center around BFP).
2. Using four (4) hexhead screws for each section, assemble both "A-B" sections thru holes provided and set on marked concrete base (FIG 2).
3. Set "D" (roof) panel on "A-B" sections and using four (4) hexhead screws fasten thru holes provided.
4. A. Using one (1) hexhead screw attach **Outside Corner Anchoring Brackets** to "A-B" sections. Fasten bracket to concrete using one anchor for each bracket (FIG 1A).
  - B. Square the "A-B" corners. Align the "B" panels so that they form a straight line. Using one (1) hexhead screw and one (1) hit pin for each bracket attach **Inside Anchoring Brackets** to "B" panels and concrete (FIG 1B).
  - C. Insert **Inside Roof Clips** in "D" (roof) panel. Using one (1) hexhead screw in each clip attach clip to "B" (side) panel (FIG 1C).



5. Set "C" panels and lock in place. (**Solid "C" panel to be DOOR panel**).
6. Provide ground-fault interrupter device in electrical circuit according to applicable codes. Install heater as per manufacturer's instructions and governing local and national codes.

**SAFE-T-COVER**  
**1-800-245-6333**  
**HCF200D-2**

7. For maximum protection it is suggested that the area between the bottom of the enclosure and the concrete base be caulked with the exception of the "C" panels. **DO NOT CAULK THE BOTTOM OF THE "C" DOOR PANELS.**

**REMOVE MASKING FILM IMMEDIATELY**  
**AFTER INSTALLATION**

*If these panels get wet when the film is still on, water will irreversibly stain the panels. Summertime heat will bake the film on the panels.*

**Model No. 300D Series  
Model No. 300TD Series**

**Contents**

- 2- "A" (end) Panels**
- 4- "B" (side) Panels**
- 1- "C" (drain door) Panel**
- 1- "C" (solid access) Panel**
- 1- "D" (roof) Panel**
- 4- Outside Corner Anchoring Brackets (1 ½" x 1 ½")**
- 4- Inside Anchoring Brackets (3" x 3")**
- 4- Inside Roof Clips**
- 8- Anchors**
- 26- Screws**
- 1- Masonry Bit**
- 1- Magnetic Chuck**

**TOOLS NEEDED**

**Hammer**

**Drill**

**¾" Wrench**