

# Part Number(s): NX180SW 180° Swivel adapter with self seizing contact Port Nut Jam Nut 3/4" Pin trim length

### **Operation Specification:**

Bandwidth
Impedance
Return Loss
Insertion Loss
Operating Voltage Rating
Operating Current Rating
Operating Temperature Range

0 MHz to 1 GHz 75 Ohms Better than -30 dB to 1 GHz Less than 0.10 dB to 1 GHz 90 Volts (@ 60 Hz continuous AC) 20 Amps (@ 60 Hz continuous AC) -40° to +140° F

#### **Tooling Requirements:**

- Two (2) <sup>3</sup>/<sub>4</sub>" wrenches
- Suitable wrenches for installing pin connector
- Cutters for pin of connector

Corporate Headquarters, 6176 East Molloy Road, East Syracuse, New York 13057 Tel: (315) 431-7200 or (800) 800-6652



# INSTALLATION INSTRUCTIONS

## NX180SW

- 1. Loosen the equipment seizure screws.
- 2. Measure and trim the pin of the NX 180 SW to the equipment manufacturer specification.
- 3. Trim the pin of the connector to <sup>3</sup>/<sub>4</sub>". Use the width of the Adapter as a pin trim guide.
- 4. Hand tighten the connector into the NX 180 SW port then wrench tighten an additional 1/8 to <sup>1</sup>/<sub>4</sub> turns while holding the adapter with another wrench.
- 5. Hand tighten the port nut of the NX 180 SW into the equipment housing then tighten an additional 1/8 to  $\frac{1}{4}$  turn with a wrench.
- 6. Hand tighten the jam nut to the port nut while holding the adapter stationary, then further tighten the jam nut 1/8 to 1/4 turn with a wrench.
- 7. Tighten the seizure screw within the equipment housing according to the manufacturer's specification.

