

Model	WATTS		
	208V	230/400V	240/415V
AX4.5	3380	4133	4500
AX7.5	6888	6888	7500
AX11	8262	10102	11000
AX14	10516	12858	14000

Model	AMPS 1 Phase		
	208V	230V	240V
AX4.5	16	18	19
AX7.5	27	30	31
AX11	40	44	46
AX14	18 & 33	20 & 36	21 & 38



See Note (2)

Model	AMPS 3 Phase (V~ 3N)			
	208V	240V	400V~N3	415V~N3
AX4.5	9	11	6	6
AX7.5	16	18	10	11
AX11	23	26	15	15
AX14	29	34	19	20

**Notes:**

- (1) Use only copper wire rated 75°C or better
- (2) AX14 single phase requires two feed circuits.  
Circuit 1 drives one element and the controls,  
Circuit 2 drives two elements.

Model	WATTS		
	208V	230/400V	240/415V
AX4.5	3380	4133	4500
AX7.5	6888	6888	7500
AX11	8262	10102	11000
AX14	10516	12858	14000

Model	AMPS 1 Phase		
	208V	230V	240V
AX4.5	16	18	19
AX7.5	27	30	31
AX11	40	44	46
AX14	18 & 33	20 & 36	21 & 38



See Note (2)

Model	AMPS 3 Phase (V~ 3N)			
	208V	240V	400V~N3	415V~N3
AX4.5	9	11	6	6
AX7.5	16	18	10	11
AX11	23	26	15	15
AX14	29	34	19	20

**Notes:**

- (1) Use only copper wire rated 75°C or better
- (2) AX14 single phase requires two feed circuits.  
Circuit 1 drives one element and the controls,  
Circuit 2 drives two elements.

